Large Crate 24" x 32" Height 9 1/2"

Supplies Needed

Treated Plywood

- 1) Black 8"x 52" (9) 1" Holes ½" Plywood
- 2) 2 Ends 8 3/8 x 24¾" ply wood9 holes 1"Hand Handle 1" x 5"
- 3) 1 Bottom 24" x 32" ½" Plywood
- 4) 1" Treated Lumber: (4) One on each corner 1 ½" x 30 9/16"
- 5) (2) 1 1/2" x 22 1/2" Top Supports
- 6) (11) Top Lathe 32" Long Door
- 7) (2) 29 1/8" Lathe
- 8) (3) 7 1/4" Lathe
- 9) (2) 22 1/2" Lathe
- 10) (3) 10" Ga Wires, 11" Long

Directions

- 1. 4 is nailed to inside of 4 corners of 2
- 2. Holes are drilled in ends and back first
- 3. 3 is nailed to bottom of 2
- 4. 1 is nailed to bottom of 2
- 5. 6 is nailed to 5 and divided equally
- 6. 5 is nailed to 4 (front and back)
- 7. 6's are nailed or stapled to top of 2
- 8. 10's are nailed on top of edge of 2 over Lathe
- 9. 7 and 8 holes are drilled in each of three
- 10. 9 wire bent (I_o_I) put through holes in 8 and put around front lathe of top and twisted- works as hinge.

